


TORCIA LASER PRO

TORCE 
LASER


POSIZIONE	CODICE	DESCRIZIONE
1	JL-10094629	Ugello AS12
	JL-10094740	Ugello BS16
	JL-10094649	Ugello CS12
	JL-10094648	Ugello ES12
	JL-10094964	Ugello FS16
	JL-10094638	Ugello AS20
	JL-10094967	Ugello BS20
	JL-10094650	Ugello C
	JL-10094647	Taglio Ugello M8 1.5
2	JL-10094656	Tubo Graduato : 600-4
3	JL-10094962	Bolt 600-2
4	JL-10094965	Collet 600-3
5	JL-10094978	Collet holder 600 : (with screw)
	JL-10094966	Connection block 600-1
6	JL-10094963	Insulation plate 500
7	-	Gas guide pipe
8	-	Gas guide pipe holder
9	-	Frame for Lente holder
10	JL-10094659	Sealing ring : 15x21x2.7
11	JL-10094971	Lente di protezione holder 300-4 : (with screw)
12	JL-10094651	Lente di protezione : D18T2
13	JL-10094968	Lente di protezione pressing ring 300-5
	JL-10095013	Sealing ring : 18.5x20.5x1.7 SUP20S
14	JL-10094659	Sealing ring : 15x21x2.7
15	JL-10094970	Supporto Lente Focus
	JL-10094972	Lente Focus cover 300-1 : (with screws)
16	JL-10094661	Lente Focus : D20x4.5 F150
	JL-10094944	Lente Focus : D20 F400 per cleaning
17	JL-10094969	Focusing Lente pressing ring 300-3
	JL-10095013	Sealing ring : 18.5x20.5x1.7 SUP20S
18	-	Connecting body
19	-	Bottom cover
20	JL-10094975	Button cover 100-2
	JL-10096338	Button
21	-	Insulation plate
22	-	Fastening ring
23	JL-10094657	Lente Collimazione : D20x5 F60
24	-	QBH holder
25	JL-10094974	Tension plate 100-1 : (with screws)
26	JL-10095019	QBH connector
27, 28, 29	JL-10094662	Lente di riflessione and its holder : 30x14T2
30	-	Regulating pipe
31	-	Motore lente
32	JL-10094973	Motor cover : (with screws)